

Vinyl gazebo assembly instructions



Step 1:
Lay out the floor sections according to the markings.



Step 2:
Make sure corners and decking surface are even. Use two 10 x 2 1/2 zinc screws at each missing floorboard and attach floor sections together.



Step 3:
Attach floorboards using the nails that are provided with the same pattern as nails in the attached floorboards.



Step 4: Fasten posts to the floor with one 10 x 3 S.S. screw at each corner. Use only one screw to fasten posts until rails are fastened.



Step 5:
Make sure that both ends of the rail are down against the floorboards, and then attach all the bottom rails to the posts with 8 x 2 S.S. screws.



Step 6:
Fasten the top rails to the posts after all the bottom rails are attached. The bottom of the horizontal rail piece should be 74" above the surface of the floorboards.



Step 7:
After all the rails are hung put the remaining screws through the baseboards into the posts.



Step 8
Put one roof section into place using a sturdy prop to hold up the center. The Approximate height of the roof can be obtained by matching the rafter to the angle of the post where it rests on. Fasten prop to the inside of the rafter.



Step 9:
Pre-drill holes for the screws into the side of the rafters. Two 10 x 2 ½ zinc screws approximately every 16 inches. Start screws before lifting next roof panel.



Step 10:
Make sure that the outside corners are even before fastening the sections together.



Step 11:
After all the roof sections are properly fastened together place the shims on top of the posts. Put the shims between rafter and rail end trim using a pry bar to shift post and roof if necessary.



Step 12:
Fasten roof to posts using four 10 x 3 S.S. screws at each post. Two screws go through the post and into the bottom of the rafters and one screw on each side goes through the end trim and into the side of the rafter.



Step 13:
Insert the roof center into the center of the ceiling and fasten with 8 x 2 stainless steel screws.



Step 14:
Attach the corner covers with 7 x 1 S.S. screws.
The V-groove in the cover should be on the inside
with the two rounded corners down.



Step 15:
Put asphalt shingles over the seam where the roof
sections meet.



Step #16
After all the seams are capped with asphalt shingles the
put the cupola on the top of the roof using 10 x 3 S.S.
screws.

